


# SETTING YOUR PERSONAL COMBINATION

Your new resettable combination padlock is preset at the factory to unlock at 0-0-0-0.

To set your own combination steps:

**Step 1** Leave dials at the opening combination 0-0-0-0 and pull out shackle.




**Step 2** Turn shackle 90° and press down as far as it will go. But before press down the shackle, please be aware that the key way on the shackle must align up to the notch on the lock body.

CH-17C/D/E



**Step 3** Holding shackle depressed and set the dials to your own combination.

**Step 4** Release shackle and return to regular position. Your new lock will now open to your personal combination.



These combination locks are suitable to lock the luggage bag, cabinet, gate, drawer, etc. Easy to remember the combination for your privacy.



Pull out the shackle (D) ;  
press the shackle down c  
Set dials to desired code.  
Rotate back the shackle.



X001N052DT

IDEALUX Vorh ngeschl...ster, 80x42mm Level 4  
新品 MADE IN CHINA